

## STEP1: initialization

1. Cut off the power supply
2. press the control pad (any button) till no display
3. made power plugged in and start initialization: press and hold M +  (up) button , the controller will show SET and desk will automatically find the highest and lowest position

operate initialization when power on each time

STEP2: Display should shows "071" on lowest position, If not please follow below instructions:

1. press M + 1 +  (down) button at the same time, display will show its base (lowest) height and flashing.
2. Press  (up) or  (down) to "071" base height.
3. Press M to save base height.